



Parts Table for ACTS-5 through ACTS-30

Part No.	Description	Qty				
		ACTS-5-8	ACTS-10	ACTS-15-20	ACTS-25	ACTS-30
02-02	Outlet Nozzle	1	1	1	1	1
02-03	Inlet Nozzle	1	1	1	1	1
02-04	Overflow Nozzle	1	1	1	1	1
02-05	Drain Nozzle	1	1	1	1	1
02-06	Automatic Filler Plate	1	1	1	1	1
02-08	Float Valve Ass'y	1	1	1	1	1
02-09	Over Flow	1	1	1	1	1
02-10	Suction Strainer	1	1	1	1	1
02-12A	Connector Pipe	1	1	1	1	1
02-16	Elbow	1	1	1	1	1
02-19	Inlet Pipe	1	1	1	1	1
03-00	Water Basin	1	1	1	1	1
04-00	Casing Supporter	3	3	3	3	4
05-01A	Casing	3	3	3	3	4
05-06	Hand Hole Cover	1	1	1	1	1
06-01	Stand Pipe	1	1	1	1	1
06-04	Stand Pipe Base	1	1	1	1	1
07-01	Stopper	2	2	2	2	2
08-01	Filling Supporter-A	3	3	3	3	4
11-00	Filling	2	2	2	2	2
12-01	Sprinkler Head	1	1	1	1	1
13-01	Sprinkler Pipe	4	4	4	4	4
13-02	End Cap	-	-	-	4	4
13-03	Eliminator	-	-	-	-	4
13-04	Lock Nut	4	4	4	4	4
14-00	Motor Frame Ass'y	1	1	1	1	1
16-01	Fan Motor	1	1	1	1	1
16-04	Fasten Nut	1	1	1	1	1
17-00	Fan Ass'y	1	1	1	1	1
18-01	Fan Guard	1	1	1	1	1
20-02	Inlet Louver	3	3	3	3	4
20-10	Louver Bracket	-	3	6	6	8
20-11	Knob Pin	6	6	6	6	8
Others	Bolts & Nut	1 Set				



Parts Table for ACTS-40 through ACTS-60

Part No.	Description	Qty			Part No.	Description	Qty		
		ACTS -40	ACTS -50	ACTS -60			ACTS -40	ACTS -50	ACTS -60
02-02	Outlet Nozzle	1	1	1	12-01	Sprinkler Head	1	1	1
02-03	Inlet Nozzle	1	1	1	12-04	Tension Wire	2	2	2
02-04	Overflow Nozzle	1	1	1	13-01	Sprinkler Pipe	4	4	4
02-05	Drain Nozzle	1	1	1	13-02	End Cap	4	4	4
02-06	Automatic Filler Plate	1	1	1	13-03	Eliminator	4	4	4
02-08	Float Valve Ass'y	1	1	1	13-04	Lock Nut	4	4	4
02-09	Over Flow	1	1	1	14-00	Motor Frame Ass'y	1	1	1
02-10	Suction Strainer	1	1	1	16-01	Fan Motor	1	1	1
02-12A	Connector Pipe	1	1	1	16-03	Fan Key	-	-	1
02-16	Elbow	1	1	1	16-04	Fasten Nut	1	1	1
02-19	Inlet Pipe	1	1	1	17-00	Fan Ass'y	1	1	-
03-01	Water Basin	1	1	1	17-01	Fan Hub	-	-	1
04-00	Casing Supporter	4	4	4	17-02	Fan Blade	-	-	3
05-01A	Casing	4	4	4	17-04	U-Bolt (Fan Blade)	-	-	3
05-06	Hand Hole Cover	1	1	1	18-01	Fan Guard	2	2	2
06-01	Stand Pipe	1	1	1	20-01A	Louver Supporter	8	8	8
06-04	Stand Pipe Base	1	1	1	20-01B	Down Plug	8	8	8
07-01	Stopper	2	2	2	20-01C	Up Plug	8	8	8
08-01	Filling Supporter-A	4	4	4	20-02	Inlet Louver	8	8	8
08-03	Filling Supporter-C	4	4	4	20-08	Wing Bolt	16	16	16
10-00	Ladder	1	1	1	20-09	Plastic Washer	16	16	16
10-03	Ladder Bracket-A	2	2	2	Others	Bolts & Nut	1 Set	1 Set	1 Set
10-04	Ladder Bracket-B	2	2	2					
11-00	Filling	2	2	2					



Parts Table for ACTS-70 through ACTS-125

Part No.	Description	Qty			Part No.	Description	Qty		
		ACTS-70-80	ACTS-100	ACTS-125			ACTS-70-80	ACTS-100	ACTS-125
02-01	Water Sump	1	1	1	12-01	Sprinkler Head	1	1	1
02-02	Outlet Nozzle	1	1	1	12-02	Center Post	1	1	1
02-03	Inlet Nozzle	1	1	1	12-03	Turnbuckle	4	4	4
02-04	Overflow Nozzle	1	1	1	12-04	Tension Wire	4	4	4
02-05	Drain Nozzle	1	1	1	13-01	Sprinkler Pipe	4	4	4
02-06	Automatic Filler Plate	1	1	1	13-02	End Cap	4	4	4
02-08	Float Valve Ass'y	1	1	1	13-03	Eliminator	4	4	4
02-09	Over Flow	1	1	1	14-00	Motor Frame Ass'y	1	1	1
02-10	Suction Strainer	1	1	1	16-01	Fan Motor	1	1	1
02-12A	Connector Pipe	1	1	1	16-03	Fan Key	1	1	1
02-16	Elbow	1	1	1	16-04	Fasten Nut	1	1	1
02-19	Inlet Pipe	1	1	1	17-01	Fan Hub	1	1	1
03-01	Water Basin	5	5	5	17-02	Fan Blade	3	4	4
04-00	Casing Supporter	6	6	6	17-04	U-Bolt (Fan Blade)	6	8	8
05-01A	Casing	4	4	4	18-01	Fan Guard	2	2	2
05-06	Hand Hole Cover	1	1	1	20-01A	Louver Supporter	8	12	12
06-01	Stand Pipe	1	1	1	20-01B	Down Plug	8	12	12
06-04	Stand Pipe Base	1	1	1	20-01C	Up Plug	8	12	12
07-01	Stopper	2	2	-	20-02	Inlet Louver	8	12	12
08-01	Filling Supporter-A	6	6	6	20-08	Wing Bolt	16	24	24
08-02	Filling Supporter-B	6	6	6	20-09	Plastic Washer	16	24	24
08-03	Filling Supporter-C	6	12	12	Others	Bolts & Nut	1 Set	1 Set	1 Set
08-04	Filling Supporter-Clamping Band	12	12	12	Water Basin Sealing Material				
10-01	Ladder (A Sec.)	1	1	1	A	Fiberglass	1 Set		
10-02	Ladder (B. Sec.)	1	1	1	B	Polyester Resin	1 Keg		
10-03	Ladder Bracket-A	2	2	2	C	Catalyst	1 Bottle		
10-04	Ladder Bracket-B	2	2	2					
11-02	Filling (1/2 Sec.)	2	-	-					
11-03	Filling (1/3 Sec.)	-	6	6					



Parts Table for ACTS-150 through ACTS-175

Part No.	Description	Qty	Part No.	Description	Qty
		ACTS-150-175			ACTS-150-175
02-01	Water Sump	1	12-01	Sprinkler Head	1
02-02	Outlet Nozzle	1	12-02	Center Post	1
02-03	Inlet Nozzle	1	12-03	Turnbuckle	4
02-04	Overflow Nozzle	1	12-04	Tension Wire	4
02-05	Drain Nozzle	1	13-01	Sprinkler Pipe	4
02-06	Automatic Filler Plate	1	13-02	End Cap	4
02-08	Float Valve Ass'y	1	13-03	Eliminator	4
02-09	Over Flow	1	14-01	Motor Frame Ass'y Main Pipe	2
02-10	Suction Strainer	1	15-01	Motor Base	1
02-12A	Connector Pipe	1	16-01	Fan Motor	1
02-16	Elbow	1	16-02	Motor Base Frame	1
02-19	Inlet Pipe	1	16-03	Fan Key	1
03-01	Water Basin	5	16-04	Fasten Nut	1
04-00	Casing Supporter	6	17-01	Fan Hub	1
05-01A	Casing	6	17-02	Fan Blade	4
05-06	Hand Hole Cover	1	17-04	U-Bolt (Fan Blade)	8
06-01	Stand Pipe	1	18-01	Fan Guard	2
06-04	Stand Pipe Base	1	20-01	Louver Supporter	12
07-02	Column	2	20-01B	Down Plug	12
08-01	Filling Supporter-A	6	20-01C	Up Plug	12
08-02	Filling Supporter-B	6	20-02	Inlet Louver	12
08-03	Filling Supporter-C	12	20-08	Wing Bolt	24
08-04	Filling Supporter-Clamping Band	12	20-09	Plastic Washer	24
10-01	Ladder (A Sec.)	1	Others	Bolts & Nut	1 Set
10-02	Ladder (B. Sec.)	1	Water Basin Sealing Material		
10-03	Ladder Bracket-A	2	A	Fiberglass	1 Set
10-04	Ladder Bracket-B	2	B	Polyester Resin	1 Keg
11-04	Filling (1/4 Sec.)	8	C	Catalyst	1 Bottle



Parts Table for ACTS-200

Part No.	Description	Qty	Part No.	Description	Qty
		ACTS-200			ACTS-200
01-02	Ring Frame	8	12-01	Sprinkler Head	1
01-05	Truss Pipe Ass'y	4	12-02	Center Post	1
02-01	Water Sump	1	12-03	Turnbuckle	4
02-02	Outlet Nozzle	1	12-04	Tension Wire	4
02-03	Inlet Nozzle	1	13-01	Sprinkler Pipe	4
02-04	Overflow Nozzle	1	13-02	End Cap	4
02-05	Drain Nozzle	1	13-03	Eliminator	4
02-06	Automatic Filler Plate	1	14-01	Motor Frame Ass'y Main Pipe	2
02-08	Float Valve Ass'y	1	15-01	Motor Base	1
02-09	Over Flow	1	16-01	Fan Motor	1
02-10	Suction Strainer	1	16-02	Motor Base Frame	1
02-12A	Connector Pipe	1	16-03	Fan Key	1
02-16	Elbow	1	16-04	Fasten Nut	1
03-01	Water Basin	8	17-01	Fan Hub	1
04-00	Casing Supporter	8	17-02	Fan Blade	4
05-01	Casing (Diffuser)	8	17-04	U-Bolt (Fan Blade)	8
05-02	Casing (Cylinder)	8	18-01	Fan Guard	2
05-06	Hand Hole Cover	1	20-01A	Louver Supporter	16
06-01	Stand Pipe	1	20-01B	Down Plug	16
06-02	Stand Pipe Base	1	20-01C	Up Plug	16
06-03	Packing	1	20-02	Inlet Louver	16
07-02	Column	2	20-08	Wing Bolt	32
08-01	Filling Supporter-A	8	20-09	Plastic Washer	32
08-02	Filling Supporter-B	8	25-01	Tie Retainer	4
08-03	Filling Supporter-C	16	25-02	Tie Retainer	4
08-04	Filling Supporter-Clamping Band	16	26-01	Turn Buckler	4
10-01	Ladder (A Sec.)	1	Others	Bolts & Nut	1 Set
10-02	Ladder (B. Sec.)	1	Water Basin Sealing Material		
10-03	Ladder Bracket-A	2	A	Fiberglass	1 Set
10-04	Ladder Bracket-B	2	B	Polyester Resin	1 Keg
11-04	Filling (1/4 Sec.)	8	C	Catalyst	1 Bottle



Parts Table for ACTS-225 Through ACTS-350

Part No.	Description	Qty		Part No.	Description	Qty	
		ACTS-225-250	ACTS-300-350			ACTS-225-250	ACTS-300-350
01-02	Ring Frame	8	8	12-01	Sprinkler Head	1	1
01-05	Truss Pipe Ass'y	4	4	12-02	Center Post	1	1
02-01	Water Sump	1	1	12-03	Turnbuckle	4	6
02-02	Outlet Nozzle	1	1	12-04	Tension Wire	4	6
02-03	Inlet Nozzle	1	1	13-01	Sprinkler Pipe	4	6
02-04	Overflow Nozzle	1	1	13-02	End Cap	4	6
02-05	Drain Nozzle	1	1	13-03	Eliminator	4	6
02-06	Automatic Filler Plate	1	1	14-01	Motor Frame Ass'y Main Pipe	2	2
02-08	Float Valve Ass'y	1	1	14-02	Motor Frame Ass'y Stay Pipe	2	2
02-09	Over Flow	1	1	15-01	Motor Base	1	1
02-10	Suction Strainer	1	1	15-02	U-Bolt (Motor)	8	8
02-12A	Connector Pipe	1	1	16-01	Fan Motor	1	1
02-16	Elbow	1	1	16-02	Motor Base Frame	1	1
03-01	Water Basin	8	8	16-03	Fan Key	1	1
04-00	Casing Supporter	8	8	16-04	Fasten Nut	1	1
04-02	Stiffener Ring-1	-	8	16-05	Lock Nut	1	1
05-01	Casing (Diffuser)	8	8	17-01	Fan Hub	1	1
05-02	Casing (Cylinder)	8	8	17-02	Fan Blade	4	4
05-06	Hand Hole Cover	1	1	17-04	U-Bolt (Fan Blade)	8	8
06-01	Stand Pipe	1	1	18-01	Fan Guard	2	4
06-02	Stand Pipe Base	1	1	20-01A	Louver Supporter	16	16
06-03	Packing	1	1	20-01B	Down Plug	16	16
07-02	Column	2	2	20-01C	Up Plug	16	-
08-01	Filling Supporter-A	8	8	20-02	Inlet Louver	16	16
08-02	Filling Supporter-B	8	8	20-08	Wing Bolt	48	48
08-03	Filling Supporter-C	16	16	20-09	Plastic Washer	48	48
08-04	Filling Supporter-Clamping Band	16	16	25-01	Tie Retainer	4	4
10-01	Ladder (A Sec.)	1	1	25-02	Tie Retainer	4	4
10-02	Ladder (B. Sec.)	1	1	26-01	Turn Buckler	4	4
10-03	Ladder Bracket-A	2	2	Others	Bolts & Nut	1 Set	
10-04	Ladder Bracket-B	2	2	Water Basin Sealing Material			
11-01	Filling (Inner Sec.)	-	2	A	Fiberglass	1 Set	
11-04	Filling (1/4 Sec.)	8	-	B	Polyester Resin	1 Keg	
11-06	Filling (1/6 Sec.)	-	12	C	Catalyst	1 Bottle	



Parts Table for ACTS-400 Through ACTS-1000

Part No.	Description	Qty				Part No.	Description	Qty			
		ACTS-400	ACTS-500	ACTS-600-700	ACTS-800-1000			ACTS-400	ACTS-500	ACTS-600-700	ACTS-800-1000
01-01	Base Plate-A	6	6	8	8	11-01	Filling (Inner Sec.)	2	2	-	2
01-02	Ring Frame	6	6	8	8	11-03	Filling (1/3 Sec.)	-	-	6	-
01-03	Truss Pipe-A1	6	6	8	8	11-06	Filling (1/6 Sec.)	-	-	-	12
01-04	Truss Pipe-A2	6	6	8	8	11-08	Filling (1/8 Sec.)	16	16	16	-
01-06	Tie Rod	6	6	8	8	11-10	Filling (1/10 Sec.)	-	-	-	20
02-01	Water Sump	1	1	1	1	12-01	Sprinkler Head	1	1	1	1
02-02	Outlet Nozzle	1	1	1	1	12-02	Center Post	1	1	1	1
02-03	Inlet Nozzle	1	1	1	1	12-03	Turnbuckle	6	8	8	10
02-04	Overflow Nozzle	1	1	1	1	12-04	Tension Wire	6	8	8	10
02-05	Drain Nozzle	1	1	1	1	13-01	Sprinkler Pipe	6	8	8	10
02-06	Automatic Filler Plate	1	1	1	1	13-02	End Cap	6	8	8	10
02-08	Float Valve Ass'y	1	1	1	1	13-03	Eliminator	6	8	8	10
02-09	Over Flow	1	1	1	1	14-01	Motor Frame Ass'y Main Pipe	2	2	2	2
02-10	Suction Strainer	1	1	1	1	14-02	Motor Frame Ass'y Stay Pipe	2	2	2	2
02-12A	Connector Pipe	1	1	1	1	15-01	Motor Base	1	1	1	1
03-01	Water Basin	12	12	16	16	15-02	U-Bolt (Motor)	8	8	8	8
04-01	Base Plate-B	6	6	8	8	16-01	Fan Motor	1	1	1	1
04-02	Stiffener Ring-1	6	6	8	8	16-02	Motor Base Frame	1	1	1	1
04-03	Truss Pipe-B1	6	6	8	8	16-03	Fan Key	1	1	1	1
04-04	Truss Pipe-B2	6	6	8	8	16-04	Fasten Nut	1	1	1	1
05-01	Casing (Diffuser)	12	12	16	16	16-05	Lock Nut	1	1	1	1
05-02	Casing (Cylinder)	12	12	16	16	17-01	Fan Hub	1	1	1	1
05-06	Hand Hole Cover	1	1	1	1	17-02	Fan Blade	4	4	4	4
06-01	Stand Pipe	1	1	1	1	17-04	U-Bolt (Fan Blade)	8	8	8	8
06-02	Stand Pipe Base	1	1	1	1	18-01	Fan Guard	4	4	4	4
06-03	Packing	1	1	1	1	19-00	Basin Supporter Ass'y	12	12	16	16
07-02	Column	2	2	2	2	20-01	Louver Supporter	36	36	48	48
08-01	Filling Supporter-A	6	6	8	8	20-01B	Down Plug	36	36	48	48
08-02	Filling Supporter-B	6	6	8	8	20-01D	Up Plug	36	36	48	48
08-03	Filling Supporter-C	18	18	24	24	20-02	Inlet Louver	18	18	24	24
08-04	Filling Supporter-Clamping Band	18	18	24	24	20-08	Wing Bolt	108	108	144	144
08-06	Filling Supporter	-	-	16	16	20-09	Plastic Washer	108			
10-01-1	Ladder (A Sec.-1)	1	1	1	1	Others	Bolts & Nut	1 Set			
10-02-2	Ladder (A. Sec.-2)	-	-	1	1	Water Basin Sealing Material					
10-02	Ladder (B Sec.)	1	1	1	1	A	Fiberglass	1 Set			
10-03	Ladder Bracket-A	2	2	2	2	B	Polyester Resin	1 Keg			
10-04	Ladder Bracket-B	2	2	2	2	C	Catalyst	1 Bottle			